


Technical Documentation VIBREX® Front Cleaner TYPE Praktik ML with hole circle tensioner



- 1. Safety instructions
- 2. Mounting instructions
- 3. Maintenance
- 4. Spare, wear and accessory parts
- 5. Dimension sheet, general and component drawings

1. Safety instructions




Working at running conveyor belt is dangerous.

Stop conveyor belt before start of mounting and, if necessary, the inlet in the transfer chute and secure against unauthorized restarting. Observe the regulations for prevention of accidents.

Only trained and practised personnel is allowed in coordination with the individual safety regulations and the mounting conditions to adjust the VIBREX conveyor belt cleaners at running conveyor belt. The control and maintenance personnel has to be instructed according to the safety regulations before the conveyor belt is taken into operation.

2. Mounting



a) Take measure a - b to determine the centre of the axle in accordance with the drum diameter out of table (page 4).

Refering to page 5:

- b) Transfer the measures to the transfer chute and mark the centre of the universal hanger mount (pos.1) in a lateral distance of 100 mm from the axle centre.
- Screw or weld angle of universal hanger mount onto both sides of the belt structure of the steel construction or onto the housing and fix hole bars.
- d) Fasten loosely by screws a bearing plate (pos. 4) with the axle bearing to the top at the hole pin.
- e) Push the positioning ring (pos. 2) and an axle bearing bush (pos. 3, collar inside) onto one axle end and insert axle end with bush into the bearing plate.
- f) Push second bearing plate bush (collar inside) and bearing plate onto the other end of the axle and screw bearing plate loosely at the the hole bars. Press axle bearing bushes into the bearing plates.
- g) Push the hole circle element (pos 5, 2 hole circle tensioners are mounted when belt width is 1200 mm or more) onto the axle end which is opposite to the conveyor belt drive and tighten the fixing screws and counter them. Press strongly the hole circle segment against the bearing plate and set positioning ring from behind against it and tighten.
- h) Fasten screws of the bearing plate strongly. Insert angle bolt (pos. 6) into the hole circle tensioner.
- i) Screw front blades (pos.8) onto the saddle axle (pos. 7).
- j) Take the angle bolt out of the hole circle tensioner. Put the tensioning wrench onto the outer hexagon of the hole circle segment and tension the cleaner. After belt contact of the front blades turn it to the next hole. Insert pin and secure.
- k) Observe cleaning effect, if necessary tension again.

3. Maintenance

According to general experiences with sophisticated machine elements the following maintenance cycles should be observed and, if necessary, adapted to the operational requirements:

- a) Weekly inspection
- b) Monthly actuation and tensioning respectively adjusting
- c) Quarter and half year checking of the final wearing date and, if necessary, preliminary exchange of the worn out scraper blades.
- d) At big plants, the completely equipped axles are often exchanged and maintained in the workshop.

4. Spare and Wear Parts

Pos.	Benennung	Bbr. A	Material	Maße	Artikel-Nr.
5 6	Hole circle tensioner cons. of : hole circle segment angle bolt tensioning wrench		aluminium steel,zinced steel,zinced		027110
7	Saddle axle	500 650 800 1000 1200 1400 1600 1800 2000	ST 37-2, coated	L = 1000 L = 1200 L = 1400 L = 1600 L = 1800 L = 2200 L = 2400 L = 2600 L = 3000	027251 027252 027253 027254 027255 027256 027257 027258 027259
8	Front blade 100x30		Polyurethane	B = 100	028421

5. Drawings:

This documentation 2.07.3.2648-... includes drawing nos.: 2.07.3.2649-...

2.04.4.2615-... 2.03.4.2527-... 2.04.3.2091-... 2.04.4.2083-...



Technical modifications reserved

